

# PANAGET

manufacture française de parquet  
DEPUIS 1929



## OILED WOOD FLOORING MAINTENANCE



### -- Initial maintenance:

After installation, on the surface free from any dirt, apply a thin coat of *Ciranova Maintenance oil clear matt* using a spray bottle. Spread the oil with microfiber or cotton cloth mop.

Recommended dosage: 1 litre per 650 sq. ft.

Allow to dry for + / - 8 hours, depending on temperature, relative humidity and ventilation.

Complete drying: 24 hours.

### -- Regular maintenance:

Whenever required, vacuum or sweep the floor to remove dust. If necessary, complete the cleaning process by diluting Ciranova Flooring soap with water and by using a wrung-out microfiber cloth.

Recommended dosage: 2 fl.oz / 1.5 gallon of water.

Allow to dry.

For domestic use, once or twice a year, apply a thin coat of *Ciranova Maintenance oil clear matt* by using a spray bottle. Spread the oil with microfiber or cotton cloth mop.

Recommended dosage: 1 litre per 650 sq. ft.

Allow to dry for + / - 8 hours, depending on temperature, relative humidity and ventilation.

Complete drying: 24 hours.

Use felt pads on the legs of chairs and all other furniture to prevent hardwood floor scratches. Keep the pads free of grit and replace as often as needed.

Place area rugs or bristle-type mats at all exterior door entries to collect larger pieces of grits, small stones, dirt, grime and moisture to limit what is tracked onto your floor.

For more information, please refer to Ciranova Flooring soap and Ciranova Maintenance oil clear matt technical sheets.

